

TECHNICAL SHEET

TSP 520-525 – Finixa wheel spray silver - light & ultrafine 400ml

Description

Two alloy silver - Ultrafine & Fine color repair tools, one is medium bright, the other is very bright and ultrafine to assure both are able to repair in a fast and easy way most of the alloy wheels on the market.

Specifications

Quick drying paint with real metallic particles.
Superior paint finish.
Suitable for both internal and external use
Easy in use and time saving

Application

Recommended for:

- Alloy rim repair and spot repair

Substrates:

- Primed surfaces.
- Alloy rims.

Pre-Treatment: Sand and degrease substrate before applying the aerosol.

Process

Personal protection:

Spray mask
Gloves
Coverall

Preparation

Clean the surfaces to be painted thoroughly and sand up to P500

The area must be dry and free of dust and grease

Shake the aerosol for 2 minutes

Spray test sample for color match

Apply several thin coats (2-3 paint) for optimal coverage.

Allow 5 minutes flash off between each layer.

Drying time (20°C at 60% humidity):

Dust-dry: after 10 minutes

Dry to touch: after approx. 30 minutes

Drying times are under the influence of room temperature and humidity and layer thickness.

Finishing

When dry the TSP 520 – TSP 525 will have a semi-gloss finish.

If needed can be over sprayed with most common 2K clear coats.

Additional Info

Disposal: The emptied aerosols are suitable for household collection.

Shelf life: 12 months when stored appropriately at a temperature of 15 to 25 °C and a relative humidity beneath 60%.

The above information is given in good faith, but the user should assure himself that the performance of the product is sufficient for his application. The quoted values are average and should not be taken as maximum or minimum values for specific purposes. Chemicar Europe cannot be held responsible for product failure unless full testing has been carried out. The client has to decide on the product suitability for their own applications.

Chemicar Europe nv
Baarbeek 2
2070 Zwijndrecht
België-Belgium

T.: +32 3 234 87 80
F.: +32 3 234 87 89
info@chemicar.eu
www.chemicar.eu